

GB Thank you for choosing a HabiStat product. Please read the instructions carefully and refer to diagrams before use. Retain all documents for future reference.

Installation Instructions:

- 1.Sit glass base on flat surface and screw four metal tubes into each corner. Only hand tighten. Fig1
- 2.Install the two back supports onto the two back tubes.
- 3.For single door models, slide the glass door onto the front left tube. For double door models, slide the glass door into the left hand side front tube and the right door onto the right hand side front tube. Fig2
- 4.Install back glass panel. For each side, fit two glass side panels into the H-Slots supplied and slide in. Ensure matt black side is on the outside. Fig3
- 5.Place the top frame (without the wire mesh top) on top of the four metal tubes. Ensure side with lip is facing forwards to provide stop for tops of doors. Locate tops of glass panels properly. Fig4
- 6.Place a screw into each of the four corners of the top frame and screw into place. Do not overtighten as this can make the doors stiff or crack the glass.
- 7.Install Wire Mesh Top and the 4 rubber caps on top of the screws to cover.
- 8.To attach the door handles, first clean the glass thoroughly, remove backing and press firmly into place.

Please note: Though our glass terrariums mesh roof is rust resilient, excess water directed onto the mesh can accelerate the rust process. Please do not spray water directly onto the mesh when maintaining your enclosure.

Warning:

- Ensure terrarium is placed on a flat surface and supported on all four corners. This is particularly important when using water in the base or a heavy substrate.
- Keep terrarium away from direct light areas with significant temperature fluctuations.
- We recommend at least a 1cm gap between the heat source and the mesh ventilation. DO NOT place a light fixture inside the terrarium.
- Take care to ensure any décor placed into the terrarium is not too close to any heat sources and that the animal can move freely
- Only use a soft cloth or sponge and water when cleaning the terrarium to avoid any scratches.
- When using a HabiStat humidifier, turn the outer cap to “ON” and remove. Push the extended humidifier hose through the inner cap. Do not remove the inner cap. Check the hose is secured before operating the humidifier.
- Do not spray water directly onto mesh.

HabiStat

GB

FR

DE

ES

IT

NL

PL

DK

Glass Terrarium Instruction Manual

- (I) Single Door: HGT4545, HGT4560
- (II) Double Door: HGT6045, HGT6060, HGT6090, HGT9145, HGT9160, HGT9190



Parts List

Base

Top Frame

Wire Mesh Top

Lock

Suction Cup

Outer Cap

Humidifier Inner Cap

Screwdriver

Front Tubes(x2)

Back Tubes(x2)

Back Supports(x2)

H-Slots(x2)
HGT6090 HGT9145
HGT9160 HGT9190 (x3)

Glass Door
(I) x1
(II) x2

Front Support
(I) Single Door Only

Side Glass(x2)

Narrow Side Glass(x2)

Rear Glass(x1)
HGT6090 HGT9145
HGT9160 HGT9190 (x2)

Door Handles
(I) x1
(II) x2

Screws(x4)

Cable Hole Covers(x6)

Rubber Caps(x4)

