## **HabiStat**

# Leopard Gecko

# Starter Kit





HSLGSKI

### GB Leopard Gecko Starter Kit Assembly Instructions:

#### 1: Insert the Heat Mat

- Slide the Heat Mat between the two panes of glass at the back of the Terrainium.
- Do not remove the foam insulation from in between the two glass panes. This will help insulate and ensure the heat is directed into the Terrainium. Please read the Heat Mat instructions carefully for any additional important information.
- Plug the Heat Mat into the socket of the Mat Stat (Thermostat).

#### 2: Position the Mat Stat Probe

- Place the Mat Stat probe into the vent cable recess. You will need to remove a tab to fit the probe in.
- Ensure the probe is positioned over the Heat Mat and above the substrate. This will help regulate the surface temperature.
- The probe should be placed towards one side of the Terrainium to create a temperature gradient within the enclosure

#### 3: Add Substrate

- Cover the bottom of the Terrainium with the substrate.
- Ensure there is only a thin layer of substrate over the position of the heat mat. This helps to avoid excessive heating and keeps the temperature in check.
- Please read the Heat Mat instructions carefully for any additional important information.

#### 4: Attach the Mini UVB Kit

- Attach the Mini UVB kit to the inside lid of the tank using the provided clips.
- Place the UVB kit cable in one of the vent cable recesses after removing a tab.

#### 5: Monitor Temperature

- Plug the Mat Stat into the mains power outlet and set the desired temperature using the adjustment knob.
- Use the included thermometer provided in the kit to monitor the temperature inside the Terrainium.
- Fix the thermometer next to the thermostat probe.
- Adjust the Mat Stat setting as necessary until the desired temperature is reached and maintained.

Note: The products enclosed in the kit may vary based on availability, but the basic setup and instructions should remain the same. Please follow all safety guidelines and read the individual instructions provided for each product for proper usage and care of your leopard gecko.

## **CONTENTS**



Classic Mattha ...

HabiStat classic Mattat ...





Terrainium 61 x 38 x 30cm (24 x 15 x 12")

Mat Stat 300 Watt

Heat Mat Mi 28 x 28cm Sha (11 x 11") 12 Watt

Mini UVB Kit, 7%UVB ShadeDweller Lamp, 8W

Sphagnum Moss











Leopard Gecko Bedding 5 kg

Gecko Flastic Hide

Water Bow

Bactericidal Cleaner

Coconut Cave x 2

Calcium Dish











Thermometer

Pure Calcium

Repton

Insecta Snack

Feeding Tongs

Monkfield Nutrition Ltd, Arthur Rickwood Farm, Chatteris Road, Mepal, Ely, Cambs, CB6 2AZ www.habistat.com info@habistat.com